



Google Home Setup

v15

Model NXG-100


NEXX GARAGE GOOGLE HOME SETUP

Nexx Garage integrated with Google Assistant Action allows you to control the opening or closing of garage door by voice command.


Following steps describes Nexx Garage Google Home setup.




- 1) Open Google Home app on your phone.
- 2) Press menu button in the upper left corner of screen.




3) Tap “*Explore*” from the menu.




4) Scroll down to “*Home Control*” and tap “*More*”.



5) Select “Nexx Garage”.




6) Nexx Garage screen, tap “LINK”.



7) At login page:

- Enter Nexx Garage account email and password
- Enter a 4 to 10 digit pin code. This pin code is required when opening/closing the garage door. Pin code is not required when checking door status. You can disable the pin code from Nexx Garage app under “Settings”.




Your account email


Your account password

Log In


[Terms of Service & Privacy Policy](#)



- 8) Once you have successfully logged in, you should receive a status of “Account now linked”.



- 9) To you through the linking process again, tap “UNLINK” and then “LINK”.



NEXX GARAGE GOOGLE HOME COMPLETED

- Possible Actions
 - “Hey Google, tell Nexx Garage to check garage door”
 - “Hey Google, tell Nexx Garage to check door”
 - “Hey Google, tell Nexx Garage to check garage”
 - “Hey Google, tell Nexx Garage to open garage door”
 - “Hey Google, tell Nexx Garage to open door”
 - “Hey Google, tell Nexx Garage to open garage”
 - “My pin code is 1 2 3 4” (use your pin code)
 - “Hey Google, tell Nexx Garage to close garage door”
 - “Hey Google, tell Nexx Garage to close door”
 - “Hey Google, tell Nexx Garage to close garage”
 - “My pin code is 1 2 3 4” (use your pin code)

Note:

You can disable/enable pin code from Nexx Garage app under “Settings”.